



THE GUITAMMER COMPANY INC.

...leaders in low frequency sound...

## Instructions for Setting Up the ButtKicker® Platform

Before beginning, please make sure you have the following:

- One ButtKicker Platform.
- Four hex head bolts.
- Four washers.
- One wrench. Not included.
- One screw driver. Not included.
- ButtKicker LFE or Concert. Sold separately.
- Power Amplifier. Sold separately.
- 12 to 14 gauge speaker wire. Not included.

### Attach the ButtKicker to the Platform:

1. Set the ButtKicker feet over the four holes in the platform.

*Note: The ButtKicker will line up with the holes two different ways. Either way will work. However, we recommend that you face the speaker wire terminal toward the back of the platform.*

2. Insert the four hex head bolts, with star washers, through the ButtKicker feet, and tighten into interior threaded tube. Tighten snugly, but do not over tighten.
3. Loosen ButtKicker speaker terminals with screw driver. Insert speaker wire ends into ButtKicker terminals and tighten. Attach other end to amplifier terminals.

*Note: You may find it helpful to also strap the speaker wire to the bottom of the ButtKicker, using a long wire tie or strap, to help prevent the wire from being pulled out of the terminal.*

**Support:** Please **DO NOT** contact the store where you purchased this product for support.

**Contact: The Guitammer Company Inc.**  
**1-888-676-2828, 8:30 am – 5:30 pm EST**  
**Email us at: [support@guitammer.com](mailto:support@guitammer.com)**  
**Visit us online at: [www.thebuttkicker.com](http://www.thebuttkicker.com)**

### Warranty:

This Guitammer Company product is warranted against defects in materials and workmanship for a period of two (2) years from the date of purchase by the original end-user. Items returned for repair under warranty will be repaired or replaced at the sole discretion of The Guitammer Company without charge for materials or labor, providing such items are returned for inspection, transportation prepaid, to The Guitammer Company or an authorized service center all repaired or replaced items will be returned freight collect. Warranties do not apply to products that have been subjected to abuse, accident, modifications, improper handling or installation, or repairs made by anyone other than The Guitammer Company or an authorized service center. The Guitammer Company shall be the final authority in the determination of all warranty service claims.